

PWJDM Nissan GTR Rear Diffuser Blades

Installation Guide

This install will take 30-60 minutes depending on how familiar you are with your car and if you have a service lift.

**We recommend you use a medium strength threadlock like Permatex Blue on all the bolts in this kit. Otherwise they may work loose over time.

Before Installation, double check to make sure you have all these components.

ITEM#	QTY	COMPONENT DESCRIPTION
1	2	PWJDM carbon rear diffuser blades
2	8	PWJDM anodized aluminum fender washers
3	8	M6 beveled head bolts
4	1	Install manual

1. Remove all the bolts on the left and right side of the stock diffuser. There are 4 smaller bolts and 4 larger bolts per side. Don't worry the diffuser will not fall off.
2. Slide the blades under the stock diffuser and align the mounting holes.
3. Replace the smaller bolts with the PWJDM fender washers and beveled bolts. We provide this new hardware because not all of the stock bolts will reach their securing nuts now that the diffuser blade is taking up space.
4. Reinstall the larger bolts.

Did you threadlock the bolts? They may vibrate loose if not.

