

PWJDM Ruckus Stem

Installation Guide

This install will take ~20 minutes depending on how familiar you are with your bike and tools.

If you want a full color version of this guide, you can download it at www.passwordjdm.com/instructions

Warning: This stem requires the use of your OEM curved washer that comes with the original handlebars.

Before installation, double check to make sure you have all these components.

ITEM#	QTY	COMPONENT DESCRIPTION
1	1	PWJDM Stem body and cap
2	1	M10x45mm Long bolt
3	1	M10 Locknut
4	4	M5 cap bolts
5	1	Install manual

